





USB to I²S Adapter Installation Instructions

1. Download the [PLL Programming Software Ver. 2.3.2](#) from Synergy Website and unzip the folder in C Drive of your computer. The folder will be automatically named iis_programming.
2. Plug the USB test cable into the USB port of your computer and the computer will find a new hardware.



3. Next select Search for suitable driver for my device which is located in the folder that you unzipped in C Drive named iis_programming.





4. After selecting the file click OK button.




5. Click Next button and the driver will be installed.



6. Now the USB to I2S Adapter Driver is installed and you should see a green LED light inside the USB Adapter lighted up.

7. Next step you have to open the I2Sprog.exe program from the folder iis_programming downloaded in C Drive.



8. You should have a selection option for interface port. (if there is no parallel port on your computer you will see only the USB port). Now you are ready to send commands to the PLL Synthesizer after you select the proper settings.

